

Handrail options for Poly Post Kit (100900)

Installation

Tools Required:

1-1/2", 1" Drill bit
Drill
Saw



Option A (H10900)

- Using at least 2 Poly Post Kits (100900), drill 1-1/2" holes in the recessed holes.
- Cut the 1.5" tube to length and slide through the drilled, recessed holes.
- Attach the universal plug on both ends of the handrail.

ITEM	QTY.	PART NO.	DESCRIPTION
1	1	R14013	HANDRAIL TUBE 1.5", 113"
2	2	S90000	1-1/2" PLUG
3	2	80556SS	PHILLIPS TECH SCREW

Option B (900035 or 900036)

- Using at least 2 Poly Post Kits (100900), drill 1" holes into the recessed holes.
- Insert the rope into the recessed holes and secure

ITEM	QTY.	PART NO.	DESCRIPTION
1	N/A	900035/3000036	ROPE, SOLD BY THE FOOT



900035



900036

